


AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx

All Prices Subject To Change without Notice



REF#	DESCRIPTION	PART NUMBER	US MSRP
1	Neck	N/A	Warranty Only
1	Jumbo Fret Wire (24)	099-1999-000	13.99
2,3	Staggered Tuners (6)	099-0820-100	52.99
4	Bone Nut (blank) (2)	099-4920-000	4.99
5	String Guides (2)	099-4911-000	6.99
6	Truss Rod Nut	099-4943-000	5.99
7	Body	N/A	Warranty Only
8	Neck Plate	099-1445-100	14.99
8 a	Neck Tilt Adjust Wrench	002-3811-049	5.99
9	Strap Buttons (2)	099-4914-000	4.99
10	Pickguard	Multiple	Varies
9 a	Pickguard Screws (24)	099-4923-000	3.99
11	Tex Mex Neck Pickup	006-3013-000	49.99
12	Tex Mex Middle Pickup	006-3012-000	49.99
13	Bridge Pickup	005-8034-000	89.99
13 a	Pickup mtg. screws (12)	006-3396-049	5.99
13 b	Humbucker mtg. screws	005-0166-049	4.99
14 *	250K Split Shaft Pot (V)	099-0830-000	6.99
15 *	250K Split Shaft Pot (T1)	099-0830-000	6.99
16 *	250K "No Load" Pot (T2)	099-0833-000	8.99
17 *	5 Way Switch	099-1367-000	11.99
18 *	Grounding lug	001-2869-000	2.99
19	Switch Tip (2) (parch)	005-6253-000	3.99
19	Switch Tip (2) (white)	099-4940-000	3.99
19	Switch Tip (2) (aged)	099-4938-000	3.99
19	Switch Tip (2) (black)	099-4939-000	3.99
20	Volume Knob (parch)	005-6254-000	2.99
21	Tone Knob (parch)	005-6255-000	2.99
20-21 a	Knob Set (3) (white)	099-2035-000	7.99
20-21 b	Knob Set (3) (aged white)	099-1369-000	6.99
20-21 c	Knob Set (3) (black)	099-1365-000	6.99
22	Output Jack	002-1956-000	2.99
22 a	Jack Nut (12)	001-6352-049	3.99
22 b	Lock Washer (12)	001-6436-049	3.99
22 c	Jack Plate (chrome)	099-1940-100	9.99
23-32	Bridge Assembly	N/A	Warranty Only
23 a*	Tremolo Claw	001-0272-100	2.99
23 b*	Tremolo Springs	001-8671-049	
23 c*	Tremolo Arm (chrome)	099-2054-000	15.99
23 d*	Bridge Mtg Screws (2)	002-8957-049	6.99
33	Back Plate	Multiple	Varies
34 *	Truss Rod Wrench (12)	002-3811-049	5.99
35 *	Molded Case	099-6101-506	

* = Not picture in diagram


Bold = Items available for warranty replacement only

AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL


Rosewood - 011-0100-xxx

Maple - 011-0102-xxx

WIRING ASSEMBLY



BRIDGE ASSEMBLY




AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx

CONTROL FUNCTIONS

5 WAY SWITCH POSITION					
5	4	3	2	1	
T1	T1 & T2	T2	T2	T2	
					← NECK PICKUP (A)
					← MIDDLE PICKUP (B)
					← BRIDGE PICKUP (C)
					← BRIDGE PICKUP (D)
	PICKUP IS ON				
	PICKUP IS OFF				
A	PICKUP (NECK)				
B	PICKUP (MIDDLE)				
C & D	PICKUP (BRIDGE)				
					INDICATES POSITION OF 5 WAY SWITCH




Fender®

AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx



REF#	DESCRIPTION	PART NUMBER
1	Neck (rosewood)	007-5398-000
1	Neck (maple)	007-5399-000
1 a	Jumbo Fret Wire (24)	099-1999-000
2,3	Staggered Tuners (set of 6)	099-0820-100
2 a	Tuner (E,B,G, D) (each)	005-6260-000
3	Tuner (A,E) (each)	002-1374-000
3 a	Tuner Mounting Washers (6)	005-8815-049
3 b	Tuner Bushings (6)	005-8820-049
4	Bone Nut (blank) (2)	099-4920-000
5	String Guides (pack of 2)	099-4911-000
6	Truss Rod Nut	099-4943-000
7	Body (3 Tone Burst)	005-4014-500
7	Body (Black)	005-6229-506
7	Body (Sienna Sunburst)	005-4015-547
7	Body (Blizzard Pearl)	005-6229-555
8	Neck Plate (with mounting screws)	099-1445-100
8 a	Neck Mtg. Screws (12)	002-1424-049
8 b	Neck Tilt Adjust Screw	003-1571-000
8 c	Neck Tilt Adjust Wrench	002-3811-049
9	Strap Buttons (2)	099-4914-000
10	Pickguard	Multiple options
10 a	Pickguard Screws (24)	099-4923-000
11	Tex Mex Neck Pickup	006-3013-000
12	Tex Mex Middle Pickup	006-3012-000
12 a	Pickup mtg. screws (12)	004-8631-049
12 b	Pickup Height Adjust Tubing	099-4916-000
13	Humbucker Bridge Pickup	005-8034-000
13 a	Humbucker pickup mtg screws (12)	005-0166-049
13 b	Humbucker pickup mtg springs (12)	005-0167-049
14 *	250K Split Shaft Pot (Volume)	099-0830-000
15 *	250K Split Shaft Pot (Tone)	099-0830-000
16 *	250K "No Load" Pot (Tone 2)	099-0833-000
17 *	5 Way Switch	099-1367-000
18 *	Grounding lug	001-2869-000


* = Not picture in diagram

Bold = Items available for warranty replacement only

AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx



REF#	DESCRIPTION	PART NUMBER
20	Volume Knob (parchment)	005-6254-000
21	Tone Knob (parchment)	005-6255-000
22	Output Jack	002-1956-000
22 a	Jack Nut (12)	001-6352-049
22 b	Lock Washer (12)	001-6436-049
22 c	Jack Plate (chrome)	099-1940-100
23	Bridge Assembly	007-5091-000
23 a*	Tremolo Claw	001-0272-100
23 b*	Tremolo Springs	001-8671-049
23 c*	Tremolo Arm (chrome)	099-2054-000
23 d*	Bridge Mtg Screws (2)	002-8957-049
23 e*	Bridge pivot screw studs (2)	002-8958-049
24	Bridge Plate (chrome)	007-5089-000
25	Bridge Saddles (each)	007-5123-000
26	Intonation Screws (12)	001-5693-049
27	Intonation Springs (A,E) (12)	001-9273-049
28	Intonation Springs (E,B,G,D) (12)	001-9281-049
29	Height Adjust Screws (E's) (ea)	007-5384-000
30	Height Adjust Screws (B,G,D,A)	007-5536-000
31	Bridge Block Mtg. Screws (12)	001-9656-049
32	Bridge Block	007-4349-000
33	Back Plate	Multiple options
34 *	Truss Rod Adjustment Wrench (12)	002-3811-049
35 *	Saddle Height Adjust Wrench (12)	001-8531-049
36 *	Molded Case	099-6101-506
37 *	"Case Candy" Kit (cables, etc.)	007-6176-000

* = Not picture in diagram

Bold = Items available for warranty replacement only




AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL


WIRING ASSEMBLY

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx



BRIDGE ASSEMBLY



Fender®

AMERICAN STANDARD STRATOCASTER® HSS, RH MODEL

Rosewood - 011-0100-xxx

Maple - 011-0102-xxx

CONTROL FUNCTIONS

5 WAY SWITCH POSITION					
5	4	3	2	1	
T1	T1 & T2	T2	T2	T2	
					← NECK PICKUP (A)
					← MIDDLE PICKUP (B)
					← BRIDGE PICKUP (C)
					← BRIDGE PICKUP (D)
	PICKUP IS ON		INDICATES POSITION OF 5 WAY SWITCH		
	PICKUP IS OFF				
A	PICKUP (NECK)				
B	PICKUP (MIDDLE)				
C & D	PICKUP (BRIDGE)				

