

American Elite HSS Shawbucker Wiring


011-4110/4111 /4112 /4020 (Lefty)

- 1: Neck
- 2: Neck + Middle
- 3: Middle
- 4: Middle + Bridge
- 5: Bridge HB

Tone 1: Neck PU
Tone 2: Middle+Neck PU

S-1 activate series & parallel mode

P/P Switch deactivates everything and sends HB direct out.



03.2.2026
Rev.A

www.axefiles.com

Graphics by Gerry Haze. all rights reserved