
Deluxe Stratocaster

014-7100/7102/7103



Switch ON:
1: Neck + Bridge
2: Neck + Middle + Bridge
3: Middle
4: Middle + Bridge
5: Bridge

Tone 1: Neck + Middle PU
Tone 2: Bridge PU

Switch OFF:
Standard N/NM/M/MB/B

Oct-7-26 Rev-A

www.axefiles.com

Graphics by Gerry Haze. all rights reserved