


Standard Greasebucket PCB Wiring

011-5110/5112 (Performer)



Pos:1: Neck Pickup

Pos:2: Neck+Bridge Pickup

Pos:3: Bridge Pickup

*Greasebucket rolls of high
without adding bass*

3.13.2026
Rev.A

www.axefiles.com

Graphics by Gerry Haze. all rights reserved